

Step 1: Choose a charging method



4 Slot Cradles:

CRD9101-4001CR 4 Slot Charge Only Cradle

CRD9000-4001ER 4 Slot Ethernet Cradle

4 Slot Cradle Kits:

CRD9101-411CES
(INTERNATIONAL)

Includes: 4 Slot Charge Only Cradle CRD9000-4001ER, Level VI Power Supply PWR-BGA12V108W0WW and DC Cord CBL-DC-381A1-01. Must purchase 3 wire AC Cord separately.

CRD9000-411EES
(INTERNATIONAL)

Includes: 4 Slot Ethernet Cradle CRD9000-4001ER, Level VI Power Supply PWR-BGA12V108W0WW and DC Cord CBL-DC-381A1-01. Must purchase 3 wire AC Cord separately.

CRD9000-410EES
(US)

Includes: 4 Slot Ethernet Cradle CRD9000-4001ER, Level VI Power Supply PWR-BGA12V108W0WW, DC Cord CBL-DC-381A1-01 and US AC Cord 23844-00-00R.

Additional Accessories 4-slot Cradles



PWR-BGA12V108W0WW
Level VI AC/DC Power Supply Replacement

AC Input: 120V

DC Output: 12V

Requires: DC Cord specific ground



CBL-DC-381A1-01

DC Line Cord
DC Line Cord
Cradles from
supply PWR
Level VI repl
14000-241R



23844-00-00R

US AC line cord
grounded, th
supplies.