



Step 1: Choosing a charging method



Single Slot Cradle:

CRD3000-1001RR Single slot USB / RS232 Cradle, w/spare battery charging. **Requires:** Power Supply PWR-BGA12V50W0WW, DC Line Cord CBL-DC-388A1-01 and Country Specific 3 wire AC Line Cord.

Single Slot Cradle Kits:

CRD3000-101RES (INTERNATIONAL) **Includes:** Single Slot Cradle CRD3000-1001RR, Level VI Power Supply PWR-BGA12V50W0WW and DC Line Cord CBL-DC-388A1-01. Must purchase 3 wire AC Cord separately.

CRD3000-100RES (US) **Includes:** Single Slot Cradle CRD3000-1001RR, Level VI Power Supply PWR-BGA12V50W0WW, DC Line Cord CBL-DC-388A1-01, and US AC Cord 23844-00-00R.

 The single slot cradle can charge all the MC31 configurations (straight shooter, rotating head and gun), charges a spare battery and has USB connection.

Additional Accessories for Single Slot Cradle



25-68596-01R

USB Cable for the cradle to the host system



25-63852-01R

Provides serial communication between the single slot cradle and a host computer.



PWR-BGA12V50W0WW

Level VI AC/DC Power Supply (Brick, replacement for PWR-14000-148R)
AC Input: 100-240V, 2.4A

DC Output: 12V, 4.16A, 50W

Requires: DC line cord and Country specific grounded AC line cord.



CBL-DC-388A1-01

DC Line Cord for running the single slot cradles or battery chargers from a single Level VI power supply PWR-BGA12V50W0WW, Level VI replacement for PWR-14000-148R.



23844-00-00R

US AC line cord, 7.5 feet long, grounded, three wire for power supplies.



25-63856-01R

Modern adapter cable used on the single slot cradle