

This is a high performance 13.56Mhz RFID smart card reader without driver, reader distance up to 80mm, it's not only simple aspect, but also stable and reliable data. Widely used for RFID Radio Frequency Identification system and project, Such as Automated parking management system, Personal identification, Access controller, Production Access control, etc

I Technical Parameters

Item	Parameters
Model	HF-IC Reader
Frequency	13.56Mhz
Support cards	MF(S50/S70/Ntag203 etc.ect. 14443A protocols cards)
Output format	10 digit dec(Default output format) (Allow user to customize the output format)
Size	104mm×68mm×10mm
Colour	Black
Interface	USB
Power Supply	DC 5V
Operating Distance	0mm-100mm(related to the card or the environment)
Service Temperature	-10°C ~ +70°C
Store Temperature	-20°C ~ +80°C
Working humidity	<90%
Read time	<200ms
Read interval	<0.5S
Weight	About 140G
Cable length	1400mm
Material of reader	ABS
Operating System	Win XP\Win CE\Win 7\Win 10\LIUNIX\Vista\Android
Indicators	Double Color LED (Red & Green) and Buzzer (“Red” means standby, “Green” means reader success)

II Instructions for use

Method of installation and use

1. Connect with computer through USB interface directly. When the buzzer sounded, reader into the self-inspection. And the same time, LED turn into red means standby.
2. Open the output of computer software,such as Notepad\ a word document or Excel sheets.
3. The mouse in Notepad or WORD document clicking.
4. Put tag on the top of reader, the software will output a data(card number) of the tag. When reading the tag, LED light change from red to green.

Detecting device is connected

Open the Device Manager of computer, If appears Humans Input Device that means Reader has successfully into computer.

III Precautions

1. Do not install the reader on the magnetic objects and metal objects, they will seriously affect the RF signal.
2. If after reading, the tag is still in the induction zone, the RF reader will not send data and without any hints.

IV Common problems

1. Operation without feedback: Please check whether the interface plugged in, whether the tag is a valid or whether another RF tag is within the reading range.
2. Data error: Please check Whether the mouse is moved, whether the reader is in a critical state and whether the cable length is too long.

V Picture

